

## **SPA Series Amplifier Current Draw—120 VAC**

4 /2 D -----

July 2016

F.-11 D-----

"Current draw" is the amount of AC current an amplifier demands while it is operating. Measurements are provided for various loads at idle, 1/8 of average full power, 1/3 of average full power, and full power, with all channels driven simultaneously. The figures shown on this sheet are for 120 VAC usage; for 230- and 100-volt operation, see the companion sheets. For typical usage, use the idle and 1/8 power figures.

1/0 0

Where an asterisk (\*) appears, the data was not available at press time. The designations "na" and "nr" respectively mean "not applicable" to the particular amplifier model and "not rated" for the particular load impedance. Bridged mono into 8 ohms is equivalent to 4 ohms per channel; into 4 ohms is equivalent to 2 ohms per channel.

	Idle		1,	/8 Power				1,	3 Power		Full Power						
	Current draw	Current draw	at 1/8 of ful	I power is meas	ured with pink		Current draw	at 1/3 of ful	I power is meas	ured with pink		Current draw at full power is measured with a 1 kHz sine					
	at idle or	noise as a si	gnal. It appro	ximates operati	ng with music or		noise as a si	gnal. It appro	ximates operati	ng with music or		wave. However, it does not represent any real-world					
	with very	voice with li	ght clipping a	nd repesents th	e amplifier's		voice with ve	ery heavy clip	ping and a very	compressed	operating condition.						
	low signal	typical "clean" maximum level, without audible clipping.					dynamic rang	ge.									
	level.	Use these figures for typical maximum level operation.					· ·										
	_																
	Load per channel ->	- 8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		
Model	Amperes	Amperes	<b>Amperes</b>	<b>Amperes</b>	Amperes		Amperes	<b>Amperes</b>	Amperes	Amperes		<b>Amperes</b>	<b>Amperes</b>	Amperes	Amperes		
SPA2-60	0.2	0.3	0.4	0.7 (bridged)	0.7 (bridged)		0.6	0.6	1.4 (bridged)	1.5 (bridged)		1.3	1.4	4.5 (bridged)	4.5 (bridged)		
SPA2-200	0.1	0.8	8.0	0.6	0.7		1.2	1.4	1.4	1.5		4.1	4.8	4.8	4.9		
SPA4-60	0.2	0.6	0.6	0.9 (bridged)			1.0	0.9	1.5 (bridged)	1.4 (bridged)		2.7	3.0	4.4 (bridged)	4.5 (bridged)		
SPA4-100	0.2	0.8	8.0	1.0			1.2	1.4	1.5	1.4		4.6	4.7	4.6	4.8		



## **SPA Series Amplifier Current Draw—230 VAC**

July 2016

"Current draw" is the amount of AC current an amplifier demands while it is operating. Measurements are provided for various loads at idle, 1/8 of average full power, 1/3 of average full power, and full power, with all channels driven simultaneously. The figures shown on this sheet are for 230 VAC usage; for 120- and 100-volt operation, see the companion sheets. For typical usage, use the idle and 1/8 power figures.

Where an asterisk (\*) appears, the data was not available at press time. The designations "na" and "nr" respectively mean "not applicable" to the particular amplifier model and "not rated" for the particular load impedance. Bridged mono into 8 ohms is equivalent to 4 ohms per channel; into 4 ohms is equivalent to 2 ohms per channel.

	Idle	1/8 Power						1,	/3 Power		Full Power						
	Current draw	Current draw	at 1/8 of ful	I power is meas	ured with pink		Current draw	at 1/3 of ful	I power is meas	ured with pink		Current draw at full power is measured with a 1 kHz sine					
	at idle or	noise as a si	gnal. It appro	ximates operati	ng with music or		noise as a si	gnal. It appro	ximates operati	ng with music or	wave. However, it does not represent any real-world						
	with very	voice with li	ght clipping a	nd repesents th	e amplifier's		voice with ve	ery heavy clip	ping and a very	compressed	operating condition.						
	low signal	typical "clean" maximum level, without audible clipping.					dynamic rang	je.									
	level.	Use these figures for typical maximum level operation.															
	_																
	Load per channel ->	8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		
Model	Amperes	Amperes	<b>Amperes</b>	Amperes	Amperes		Amperes	<b>Amperes</b>	Amperes	Amperes		<b>Amperes</b>	<b>Amperes</b>	Amperes	Amperes		
SPA2-60	0.1	0.4	0.4	0.5 (bridged)	0.6 (bridged)		0.5	0.5	0.7 (bridged)	0.7 (bridged)		0.8	0.8	1.7 (bridged)	1.7 (bridged)		
01 AL 00	0.1	0.1	0	o.o (b. lagoa)	o.o (briagoa)		0.0	0.0	on (Sinagoa)	o.r (bridged)		0.0	0.0	· · · (Dilagoa)	(		
SPA2-200	0.1	0.4	0.5	0.4	0.4		0.7	0.8	0.9	0.9		2.1	2.7	2.7	2.8		
	***	_												. 0 ,			



## **SPA Series Amplifier Current Draw—100 VAC**

July 2016

"Current draw" is the amount of AC current an amplifier demands while it is operating. Measurements are provided for various loads at idle, 1/8 of average full power, 1/3 of average full power, and full power, with all channels driven simultaneously. The figures shown on this sheet are for 100 VAC usage; for 230- and 120-volt operation, see the companion sheets. For typical usage, use the idle and 1/8 power figures.

Where an asterisk (\*) appears, the data was not available at press time. The designations "na" and "nr" respectively mean "not applicable" to the particular amplifier model and "not rated" for the particular load impedance. Bridged mono into 8 ohms is equivalent to 4 ohms per channel; into 4 ohms is equivalent to 2 ohms per channel.

	Idle 1/8 Power							1,	/3 Power		Full Power						
	Current draw	Current draw	at 1/8 of ful	I power is meas	ured with pink		Current draw	at 1/3 of ful	I power is meas	ured with pink		Current draw at full power is measured with a 1 kHz sine					
	at idle or	noise as a signal. It approximates operating with music or					noise as a sig	gnal. It appro	ximates operati	ng with music or		wave. However, it does not represent any real-world					
	with very	voice with lig	ht clipping a	nd repesents the	e amplifier's		voice with ve	ery heavy clip	ping and a very	compressed	operating condition.						
	low signal	typical "clean" maximum level, without audible clipping.					dynamic rang	je.									
	level.	Use these figures for typical maximum level operation.															
	_																
	Load per channel ->	- 8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		8Ω	4Ω	70V	100V		
Model	Amperes	Amperes	<b>Amperes</b>	Amperes	Amperes		Amperes	<b>Amperes</b>	Amperes	Amperes		<b>Amperes</b>	<b>Amperes</b>	Amperes	Amperes		
SPA2-60	0.2	0.5	0.5	0.7 (bridged)	0.9 (bridged)		0.7	0.7	1.5 (bridged)	1.3 (bridged)		1.6	1.8	3.6 (bridged)	4.4 (bridged)		
SPA2-200	0.1	0.8	8.0	0.7	0.8		1.4	1.7	1.6	1.5		4.8	4.8	4.8	4.9		
SPA4-60	0.2	0.7	0.7	1.2 (bridged)			1.2	1.1	1.3 (bridged)	1.7 (bridged)		3.4	3.6	4.0 (bridged)	4.3 (bridged)		
SPA4-100	0.2	0.7	0.7	1.1			1.3	1.3	1.6	1.7		3.8	3.9	4.6	4.7		