






QSC Systems Technical Notes

AcousticCoverage™ Series Loudspeakers

Technique for easier fitment of loudspeaker grille

Follow this technique to make it easier to fit the grille into an AcousticCoverage™ Series ceiling loudspeaker.

Inserting one side of the grille first into the slot in the enclosure may make it impossible to get the rest of the grille seated. Instead, insert the top edge of the grille into the slot evenly all the way around its circumference, as shown.



Then press the grille fully into the enclosure until it is fully seated. The grille is designed to compression-fit securely in place.

Revision A—18 March 2020

QSC Systems **Technical Notes**

AcousticCoverage™ Series Loudspeakers





