


Single Presenter



Diagram example: Boardroom



User Experience

- Presenter camera starts in a user-defined default position and automatically tracks presenter in "Presenter Tracking area"
- When presenter leaves "Presenter Tracking area", Presenter camera moves to user-defined fallback position (such as wide view of room)

Single Presenter + Static View






Diagram example: Training Room/Classroom



User Experience

- Presenter camera starts in a user-defined default position and automatically tracks presenter in "Presenter Tracking area"
- Static View camera provides a cropped, stationary view of whiteboard when presenter enters "Trigger Zone – Whiteboard View"
- If there is no presenter in "Presenter Tracking area" or "Trigger Zone – Whiteboard View", Presenter camera returns to user-defined fallback position (such as wide view of room)



- 3

Multi-Presenter





Diagram example: Lecture Hall



User Experience

- Presenter camera starts in a user-defined default position and automatically tracks presenter in "Presenter Tracking area"
- When a second presenter is detected in "Presenter Tracking area", live feed switches to Conductor camera for a wider field-of-view of both people
- Live feed remains on Conductor camera until one presenter leaves the "Presenter Tracking area"